



TILT-IN-SPACE TREKKER™

STANDARD SPECIFICATIONS

MEASUREMENTS:

INCHES

HCPCS:E1234

Δ- Weight of chair is without front rigging

Use only Convaid options and parts on Convaid products. Convaid parts are not interchangeable with other manufacturer's products. Replace any worn parts immediately.

Note: Convaid maintains a policy of continual product improvement; therefore, we reserve the right to make changes without notice.

	TR12	TR14
Seat Width 	11.75	13.75
Seat Depth 	6 – 12	9 – 16
Seat Back Height 	15 – 21	17 – 26
Seat to Footplate 	4 – 13	7.5 – 16.5
Recline Adjustment 	80°– 110° 80°– 170°	80°– 110° 80°– 170°
Tilt Adjustment 	-5° to 45°	-5° to 45°
Overall Height 	37.5	37.5
Overall Length Δ 	42.5	42.5
Overall Width 	24.3	26.3
Folded Length Δ 	39	39
Folded Width 	24.3	26.3
Folded Height 	13.5	13.5
Headrest Extension 	8	8
Shoulder Strap Height 	14.5 – 20.5	15 – 23
Footplate Adjustment Angle 	±15°	±15°
Weight Capacity 	75 lbs	110 lbs
Weight of Base 	23 lbs	23 lbs
Weight of Seating Module Δ 	7 lbs	8 lbs
Total Weight of Chair 	30 lbs	31 lbs
Trekker Ventilator Hard Tray 	11.9 x15.4	11.9 x 17.4
Lateral Height Range 	5 – 13	10 – 15
Lateral Width Range 	9 – 11.5	11 – 13.5
Hip Guide Width Range 	8 – 11	8 – 13



TILT-IN-SPACE TREKKER™

STANDARD SPECIFICATIONS

MEASUREMENTS:

CENTIMETERS

HCPCS:E1234

Δ- Weight of chair is without front rigging

Use only Convoid options and parts on Convoid products. Convoid parts are not interchangeable with other manufacturer's products. Replace any worn parts immediately.

Note: Convoid maintains a policy of continual product improvement; therefore, we reserve the right to make changes without notice.

	TR12	TR14
Seat Width 	30	35
Seat Depth 	15 - 30	23 - 41
Seat Back Height 	38 - 53	43 - 66
Seat to Footplate 	10 - 33	19 - 42
Recline Adjustment 	80° - 110° 80° - 170°	80° - 110° 80° - 170°
Tilt Adjustment 	-5° to 45°	-5° to 45°
Overall Height 	95.25	95.25
Overall Length Δ 	108	108
Overall Width 	62	67
Folded Length Δ 	99	99
Folded Width 	61.7	66.8
Folded Height 	34.3	34.3
Headrest Extension 	20.3	20.3
Shoulder Strap Height 	37 - 52	38 - 58
Footplate Adjustment Angle 	±15°	±15°
Weight Capacity 	34 kg	50 kg
Weight of Base 	10.4 kg	10.4 kg
Weight of Seating Module Δ 	3.18 kg	3.6 kg
Total Weight of Chair 	13.6 kg	14 kg
Trekker Ventilator Hard Tray 	30.2 x 39	30.2 x 44.2
Lateral Height Range 	12.7 - 33	25.4 - 38.1
Lateral Width Range 	22.9 - 29.2	27.9 - 34.3
Hip Guide Width Range 	20.3 - 27.9	20.3 - 33